

RESERVEDLSINFORMATION / PARTS INFORMATION

728-serien - Reservdelslista

Ingersoll Rand 728NA3 · 728LA2 · 728JA1


Originaldokument: Ingersoll Rand

Tillhandahålls av Professional Technologies Sweden AB

Original document by Ingersoll Rand, provided by

Professional Technologies Sweden AB - authorized Ingersoll Rand distributor.


Produkt / Product: skanna QR-koden · scan QR



Service · Kalibrering · Originalreservdelar

Service · Calibration · Genuine spare parts

Series 728 Air Drill - Exploded View



(Dwg. TPA628-5)

Series 728 Air Drill - Parts List

Item	Part Description	Part Number	Item	Part Description	Part Number
1	Motor Housing Assembly		24	Gear Head Planet Gear (3 for 728N)	728J-10
	For 728J and 728L	728J-A40	25	Rotor Pinion (for 728J and 728N)	728J-17
	For 728N	728N-A40	26	Gear Head Thrust Plate (for 728N)	728N-80
	Motor Housing		27	Ring Gear (1 for 728J and 728L; 2 for 728N)	728-406
1A	For 728J and 728L	728J-B40	28	Front Spindle Bearing (2)	728-510
	For 728N	728N-B40	29	Inner Spindle Bearing Spacer	728-111
	Warning Label	WARNING-7-99	30	Outer Spindle Bearing Spacer	728-112
	• ♦ 2 Rear Rotor Bearing	728-24	31	Bearing Cage Assembly	728-A107
• ♦ 3	Air Strainer Screen	D92-61	• ♦ 32	Spindle Bearing Retainer	4E-118
4	Inlet Bushing	R001-182	• ♦ 33	Spindle Bearing Snubber	AF120-294
5	Exhaust Plate	728-123	34	Drill Chuck	
• ♦ 6	Exhaust Plate Screen	728-122		For 728JA1 (0 to 3/8" capacity) (standard)	6A-99
• ♦ 7	Exhaust Silencer	728-310		For 728JA1 (0 to 1/4" capacity) (heavy duty)	R00A-99
• ♦ 8	Throttle Valve Bushing Assembly	728-A503		For 728LA2 (0 to 3/8" capacity)	7801-99-6
• ♦ 9	Throttle Valve Bushing O-ring (3)	AF120-290		For 728NA3 (0 to 1/2" capacity)	7806-99-8
• ♦ 10	Throttle Valve Face	R000BR1C-283		For 728J6K or 728L6K (0 to 3/8" capacity) (keyless)	728-99-KC5
11	Bushing Retaining Pin	5UT-757		For 728N8K (0 to 1/2" capacity) (keyless)	728-99-KC8
12	Rear End Plate Assembly	728-A12	35	Nameplate	
• ♦ 12A	End Plate Gasket	728-739		For 728JA1	728JA1-301
• ♦ 3	Rear End Plate Retainer	728-38		For 728J6K	728J6K-301
14	Rotor	728-53		For 728LA2	728LA2-301
• ♦ 15	Vane Packet (set of 4 Vanes)	728-42-4		For 728L6K	728L6K-301
16	Cylinder Assembly	728-A3		For 728NA3	728NA3-301
17	Front End Plate	728-11		For 728N8K	728N8K-301
• ♦ 18	Front Rotor Bearing	R0A2-22	* Drill Chuck Key		
19	Front Rotor Bearing Support	728-13A		For 6A-99 Chuck	R0J-J253
20	Spacer (1 for 728J and 728L; 2 for 728N)	728-118		For R00A-99 Chuck	R00A-J253
21	Spindle Assembly (includes planet gear shafts)			For 7801-99-6 Chuck	728N-253
	For 728J	728J-A8		For 7806-99-8 Chuck	728N-253
	For 728L	728L-A8	* Exhaust Plate Assembly (for piped-away exhaust) (includes crimped-on hose fitting)		D1400-A123
	For 728N	728J-A8	* Dead Handle (for 728N)		728N-A48
22	Spindle Planet Gear (3)		* Tune-up Kit (includes illustrated parts: 2, 3, 6, 7, 9 [3], 10, 12A, 13, 15 and 18)		728-TK3
	For 728J	728J-10			
	For 728L	728L-10			
	For 728N	728J-10			
23	Gear Head (includes planet gear shafts) (for 728N)	728N-A216			

* Not Illustrated

• To keep downtime to a minimum, it is desirable to have on hand certain repair parts. We recommend that you stock one (pair or set) of each part indicated by a bullet (•) for every four tools in service.

♦ Indicates Tune-up Kit part.

Parts and Maintenance

When the life of the tool has expired, it is recommended that the tool be disassembled, degreased and parts be separated by material so that they can be recycled.

Tool repair and maintenance should only be carried out by an authorized Service Center.

Refer all communications to the nearest **Ingersoll Rand** Office or Distributor.

Related Documentation

For additional information refer to:

Product Safety Information Manual 04580353.

Product Information Manual 03527256.

Maintenance Information Manual 16606022.

Manuals can be downloaded from www.ingersollrandproducts.com.



www.ingersollrandproducts.com
© 2010 **Ingersoll Rand** Company

16606014
Edition 2
May 2010